



### THINGS YOU NEED

1. HTC FEELER
2. PHILLIPS SCREWDRIVER
3. T6 HEX SCREWDRIVER

### OTHER MATERIALS (NOT SHOWN)

1. GUITAR PICK
2. TWEEZERS



REMOVE THE SCREWS WITH T6 SCREWDRIVERS  
USE A PICK TO REMOVE THE BACK COVER FROM  
THE FRONT COVER..LIKE IN TANGER/VOYAGER



REMOVE THE  
MIDDLE SCREW



USE TWEEZERS TO PULL THIS FLEX. SLOWLY AND GENTLY THIS IS A SENSITIVE FLEX. (THANKS TO ABUSEMEMORE FOR THE TIP)

